

September 2008

**Anleitung: Kardan Crash Pad  
BMW R1200****Instruction: Cardan Crash pad  
BMW R1200**

Lieferumfang:  
1x Crashpad  
1x Schraube  
1x Klemmhülse  
1x Zughülse  
2x Aufkleber

Contains:  
1x Crashpad  
1x Srew  
1x Clamping sleeve  
1x sleeve  
2xStickers



**Achtung! Wichtiger Hinweis zur  
Montage**  
**Achten Sie auf festen Sitz des  
Crashpads**  
**Nach 50 Kilometern die Schraube  
nochmals kontrollieren**

**Attention! Important notes,  
explanations**  
**Make shure that the crashpad is  
tightly fixed**  
**After 50km, please check the screw  
again!**

**Montage**

Entfernen Sie die schwarze  
Kunststoffabdeckung des Kardangelenkes.

Stecken Sie die Schraube durch das Pad,  
schieben Sie die Klemmhülse über die  
Schraube und schrauben Sie die Zughülse  
leicht auf das Ende der Schraube.

Setzen Sie das Crashpad in die Öffnung  
am Kardangelenk ein.

Ziehen Sie die Schraube fest.

Sie haben zwei Aufkleber zur Auswahl um  
die Schraubenöffnung zu verdecken:  
Touratech Streetline ROT,  
Touratech GELB.

**Mounting**

Remove the plastic cover of the  
Cardan.

Put the screw through the carshpad, slide  
the clamping sleeve over the screw and  
put the sleeve at the end of the screw.

Insert the Crashpad into the opening of  
the cardan.

Screw it tightly.

You have two stickers at your choice to  
close the front of the crashpad:  
Touratech Streetline: RED,  
Touratech YELLOW

